Secure Microblock and Sensors on Femur

F1 — Secure on Femur — ⓛ

Insert pin at knee center and point toward hip

- Drill center pin in same location as an IM Rod; aiming into canal
- Secure with oblique pins

F2 — Input A/P Offset — ⓛ

Read Scale

2 Input:

- Read number where pin slider lines up with mark and input into unit

F3 — Attach Sensors — ⓛ

- Attach Sensor and Unit

Register Femur

F4 — Maneuver Leg — Ⓡ

- Maneuver leg - pivot on heel during abduction/adduction move
- Flex hip; return foot gently to starting spot

Set Resection Plane

F5 — Set Resection Plane — ⓛ

F/E 3.0°   V/V 0.0°

- Set varus / valgus angle to desired setting; mechanical axis is 0.0 degrees
- Set flexion / extension to desired flexion angle of femoral component (implant specific)

Set Resection Depth

**F6** — Set Resection Depth — ⓛ

F/E 0.0°   V/V 0.0°

- Place Distal Guide on femoral jig and set resection depth. Release gold plate. Pin Femoral Cutting Block in place
- Remove resection depth guide, remove oblique pins and center pin from femoral jig
- Remove Microblock by pulling distally. Femoral cutting block stays pinned in position
- Resect Distal Femur

Secure Jig on Tibia

T2 Secure on Tibia ⓛ

ACL

Medial 1/3 Tubercle

- Rest white shin spacer pad on tibial crest
- Secure calf strap
- Align proximal guide with medial 1/3 of tibial tubercle
- Secure with 2 or 3 pins

Register Tibia

T4 Match Probe Offsets ⓛ

Register:
Offset
Lateral
Medial

- Read Midline Probe offset
- Lift both side levers to unlock
- Extend distal probe to match offsets

T5 Register Lat. Malleolus ⓛ

Register:
✔Offset
Lateral
Medial

- Touch most prominent edge of lateral malleolus with distal probe
- Press center button to register

**T5** Register Lat. Malleolus ⓛ

Register:
✔Offset
✔Lateral
Medial

- Touch most prominent edge of medial malleolus with distal probe
- Press center button to register

Set Resection Plane

T7 Set Resection Plane ⓛ

PS 3.0°   V/V 0.0°

- Set varus / valgus angle to desired setting. Push V/V Lever down into locked position
- Set Posterior Slope to desired setting. Push P/S Lever down into locked position

Set Resection Depth

T8 Set Resection Depth ⓛ

PS 3.0°   V/V 0.0°

- Insert cutting block and attach resection stylus to cutting block
- Set resection depth
- Push release plate of tibial jig up to adjust height of cutting block
- Resect tibia

OrthAlign

RX Only. Please refer to instructions for use for full safety information.
www.OrthAlign.com | info@OrthAlign.com | 001079 Rev B 05/2020